
# EEL 7170: Introduction to IoT

Lab Report



॥ त्वं ज्ञानमयो विज्ञानमयोऽसि ॥

Anushkaa Ambuj Name:

Roll Number: **B21ES006** 

B.Tech in ES Program:

## Lab 6: InfluxDB and Grafana Integration

21 October, 2024

### 1 Assignment

#### 1.1 Objective

The objective of this lab is to set up data pipelines from sensors to store real-time sensor data in an InfluxDB database and visualize it using Grafana dashboards for effective monitoring and visualization.

#### 1.2 Components Used

- Raspberry Pi
- InfluxDB
- Grafana
- Python (for data insertion)
- LIDAR Sensor (VL53L0X)

#### 1.3 Procedure

#### Part 1: Installing InfluxDB on Raspberry Pi

• Step 1: Update and upgrade all packages

```
sudo apt update
sudo apt upgrade
```

• Step 2: Add the InfluxDB repository

```
curl https://repos.influxdata.com/influxdata-archive.key | gpg --dearmor |
sudo tee /usr/share/keyrings/influxdb-archive-keyring.gpg >/dev/null
```

• Step 3: Register the InfluxDB repository in your system

```
echo "deb [signed-by=/usr/share/keyrings/influxdb-archive-keyring.gpg]
https://repos.influxdata.com/debian $(lsb_release -cs) stable"
| sudo tee /etc/apt/sources.list.d/influxdb.list
```

• Step 4: Install InfluxDB

sudo apt install influxdb

• Step 5: Start and Enable InfluxDB

```
sudo systemctl unmask influxdb
sudo systemctl enable influxdb
sudo systemctl start influxdb
```

- Step 6: Create a database and insert data
  - Start the InfluxDB client by typing influx in the terminal.
  - Create a new database:

CREATE DATABASE <YOUR\_DATABASE\_NAME>
USE <YOUR\_DATABASE\_NAME>

- Insert sample data:

INSERT temperature,location=living\_room value=20
INSERT temperature,location=living\_room value=10

#### Part 2: Installing Grafana on Raspberry Pi

• Step 1: Add the APT key used to authenticate packages

```
sudo mkdir -p /etc/apt/keyrings/
```

• Step 2: Add the InfluxDB repository

```
curl https://repos.influxdata.com/influxdata-archive.key | gpg --dearmor |
sudo tee /usr/share/keyrings/influxdb-archive-keyring.gpg >/dev/null
```

• Step 3: Register the InfluxDB repository in your system

```
echo "deb [signed-by=/usr/share/keyrings/influxdb-archive-keyring.gpg]
https://repos.influxdata.com/debian $(lsb_release -cs) stable"
| sudo tee /etc/apt/sources.list.d/influxdb.list
```

• Step 4: Install Grafana

```
sudo apt-get update
sudo apt-get install -y grafana
```

• Step 5: Start and Enable Grafana

```
sudo /bin/systemctl enable grafana-server
sudo /bin/systemctl start grafana-server
```

#### • Step 6: Access Grafana

- Open a browser and navigate to localhost:3000.
- Login using admin as both username and password.

#### • Step 7: Configure InfluxDB as a data source

- Go to Data Sources and select InfluxDB.
- Configure the InfluxDB settings, including the database name and network configurations.

```
Enter URL => http://localhost:8086
```

#### • Step 8: Create a Grafana dashboard

- Go to Dashboards and create a new one.
- Add visualization panels for your data.
- Choose the Table in the input space beside FROM.

#### Part 3: Writing to InfluxDB using Python

• Step 1: Install the InfluxDB Python library

```
python3 -m pip install influxdb
```

#### • Step 2: Use Python script to insert Lidar data into the database

- Use the same virtual environment we have used in Lab3.
- Modify the script to use your database and table names.
- Modify the json-body in the influx.py code file provided.

#### 1.4 Code

#### 1.4.1 lidar.py

```
import time
  import board
  import busio
  import adafruit_v15310x
5
  # Initialize I2C bus and sensor.
6
  i2c = busio.I2C(board.SCL, board.SDA)
  v153 = adafruit_v15310x.VL53L0X(i2c)
9
  # try:
10
11 #
        Main loop will read the range and print it every second.
12 #
        while True:
            print("Range: {0}mm".format(v153.range))
13 #
14 #
            time.sleep(0.2)
# except KeyboardInterrupt:
```

Listing 1: Function to fetch data from LIDAR

#### 1.4.2 influx.py

```
from influxdb import InfluxDBClient
  from lidar import fetch_data
2
  # Connect to InfluxDB
  client = InfluxDBClient(host='localhost', port=8086)
6
  # Choosing the DB
  client.switch_database('ROOM6')
  # Running infinite loop to insert data from LIDAR continuously.
9
  \# Stop the INSERT by KeyboardInterrupt(Ctrl+C)
10
  while True:
11
12
       try:
           data = fetch_data()
13
           json_body = [
14
               {
15
                    "measurement": "B21ES006",
16
                    "fields": {
17
                                  : data
                        "value"
18
19
               }
20
21
           print(client.write_points(json_body)) ## prints TRUE if insert is
               successful
       except KeyboardInterrupt:
           print("exit")
```

Listing 2: Function in Listing 1 is used to INSERT the fetched data from LIDAR to InfluxDB (Here, DATABASE\_NAME = 'ROOM6' & TABLE\_NAME = 'B21ES006')

#### 1.5 Observations & Results

- Successfully installed and configured InfluxDB and Grafana.
- Created a database and inserted sensor data using Python.
- Configured Grafana to visualize real-time data from InfluxDB.
- The Lidar data was visualized successfully on the Grafana dashboard.




Figure 1: Real-time LIDAR data inserted in InfluxDB




Figure 2: Visualizing the mean values of LIDAR data inserted into InfluxDB with a timestamp.




Figure 3: Visualizing the number of entries inserted in the InfluxDB




Figure 4: Visualizing the LIDAR data entries from all tables in our InfluxDB